



Canada
Helitech Support Services LLP.
1640 Threshold Drive
Abbotsford, BC V2T 6H5
Tel: 604-557-9690 Fax: 604-557-9691
www.helitechss.com

United States
Helitech Corporation
7056 Portal Way, Building K2
Ferndale, Washington 98248
Tel: 360-366-0129 Fax: 360-366-5037
www.helitechss.com




S76 AIRCRAFT PANELS

WE PROVIDE 24/7 SUPPORT TO OPERATORS AROUND THE GLOBE WITH OUR S76 IN-HOUSE MAINTENANCE TECHNICIANS! WHETHER YOU NEED AN INSPECTION, REPAIR, MAJOR OVERHAUL, OR A QUICK EXCHANGE, HELITECH SUPPORT IS HERE FOR YOU!

INTERIOR/EXTERIOR PANELS


HELITECH IS PLEASED TO OFFER COMPLETE PANEL REPAIRS FOR THE SIKORSKY S76 AIRCRAFT. UTILIZING STATE-OF-THE-ART EQUIPMENT AND FACILITIES, HELITECH HAS BECOME A WORLDWIDE SUPPLIER OF S76 STRUCTURAL AND COMPOSITE REPAIRS.



FOR MORE INFORMATION REGARDING OUR S76 PANELS PLEASE CONTACT
GREG BARTLETT AT TEL: 360-366-0129 OR BY EMAIL AT GREGB@HELITECHSS.COM.




Sikorsky S76 Outer Panels




Sikorsky S76 Outer Panels

PART NUMBER	DESCRIPTION		PART NUMBER	DESCRIPTION
76203-03003-059	Side Panel		76205-08001-072	Forward Fairing
76203-03003-060	Side Panel		76207-02002-041/043/049	Floor Panel - LH
76203-03007-045	Side Panel		76207-02002-051/053	Floor Panel - LH
76203-03007-046	Side Panel		76207-02002-042/044	Floor Panel - RH
76203-03034-041	Side Panel - LH		76207-02002-050/052/054	Floor Panel - RH
76203-03034-042	Side Panel - RH		76207-02006-045	Side Panel - LH
76203-05001-116	Leading Skin (Aluminum)		76207-02006-046	Side Panel - RH
76205-08001-013	Forward Fairing		76207-03002-041	Door Panel - LH
76205-08001-015	Forward Fairing		76207-03002-043	Door Panel - RH
76205-08001-057	Forward Fairing		76303-07800-102	Aft. Engine Cowl
76205-08001-071	Forward Fairing			


Sikorsky S76 Inside Panels




Sikorsky S76 Inside Panels



Sikorsky S76 Inside Panels



Sikorsky S76 Inside Panels




Sikorsky

S76 Inside Panels

PART NUMBER	DESCRIPTION		PART NUMBER	DESCRIPTION
76076-60035-045	Shelf Assembly - LH		76204-02005-043	Fuel Cell Cover
76076-60035-046	Shelf Assembly - RH		76204-02005-044	Baggage Panel
76076-60035-048	Shelf Assembly - LH		76204-02006-047	Floor Panel - LH
76076-60035-050	Shelf Assembly - RH		76204-02006-048	Floor Panel - RH
76076-60035-052/053/054	Shelf Assembly - LH		76204-02007-042	Cabin Floor Center Panel
76201-02005-043	STA 188 Bulkhead LH		76204-02021-041	Panel Assembly - LH
76201-02005-044	STA 188 Bulkhead RH		76204-02021-042	Panel Assembly - RH
76204-02002-043/051	Cabin Floor - LH		76600-02034-047	Shelf Assembly - LH
76204-02002-050/052	Cabin Floor - RH		76600-02034-048	Shelf Assembly - RH
76204-02005-041	Baggage Panel - LH		76600-02034-049	Shelf Assembly - LH
76204-02005-042	Baggage Panel - RH		76600-02034-050	Shelf Assembly - RH

Sikorsky S76 Tail & Under Belly Panels



Sikorsky S76 Tail Panels

PART NUMBER	DESCRIPTION		PART NUMBER	DESCRIPTION
76200-06000-070	Horizontal Fin			
76207-10005-045	Nose Wheel Door - LH			
76207-10005-046	Nose Wheel Door - RH			
76251-01108-057	Nose Float Cover - LH			
76251-01108-058	Nose Float Cover - RH			